



\*1: No AF-assist beam from Speedlite Transmitter ST-E2.  
 \*2: Battery Pack LP-E6 can also be used.  
 \*3: AC Adapter Kit ACK-E6 can also be used.  
 \*4: Charging with USB Power Adapter PD-E1 is only available for LP-E6N (not LP-E6).

\*5: The digital compass cannot be used with the camera, and the shooting direction is not recorded.  
 \*6: Make sure WFT-E7 (Ver. 2) or WFT-E7 firmware is up to date. Note that Interface Cable IFC-40AB III or IFC-150AB III is required.